

DTC	DESCRIPTION	POSSIBLE CAUSES	ACTION
C1130-66	Air Spring Air Supply - Signal has too many transitions /events	<ul style="list-style-type: none"> <li>■ Air spring leak</li> <li>■ Leak in air harness to air spring</li> <li>■ Corner valve leak to gallery</li> <li>■ Compressor assembly fault</li> <li>■ Vehicle driven while system in "Tight Tolerance" mode</li> </ul>	<ul style="list-style-type: none"> <li>■ Visually inspect the system for air leakage. Where possible, refer to the guided diagnostic routine for this DTC on the approved diagnostic system</li> </ul>
C1130-7A	Air Spring Sir Supply - Fluid leak or seal failure	<ul style="list-style-type: none"> <li>■ Detached or burst air pipe</li> <li>■ Leaking air spring or pipe to air spring (large leak)</li> <li>■ Loose pipe connection</li> <li>■ Insufficient pressure from compressor</li> <li>■ Height sensor fault</li> </ul>	<ul style="list-style-type: none"> <li>■ Visually inspect the system for an excessive air leak. Check the height sensor linkage(s) for damage/restrictions. Visually inspect the air harness for evidence of melting, crushing, kinking or collapsing. Where possible, refer to the guided diagnostic routine for this DTC on the approved diagnostic system</li> </ul>
C1131-92	Air Supply - Performance or incorrect operation	<ul style="list-style-type: none"> <li>■ Loose or burst air pipe</li> <li>■ Detached air pipe</li> <li>■ Leaking pipe from reservoir valve block to air supply unit or either axle valve block</li> <li>■ Insufficient pressure from compressor</li> <li>■ Reservoir valve block piped incorrectly</li> </ul>	<ul style="list-style-type: none"> <li>■ Visually inspect the system for air leakage. Check the reservoir valve block pipes for correct routing and installation</li> </ul>
C1138-23	Access Switch - Signal stuck low	<ul style="list-style-type: none"> <li>■ Switch signal stuck low (switch on driver's door) <ul style="list-style-type: none"> <li>■ Switch harness short to ground</li> <li>■ Switch stuck in pressed position</li> <li>■ Driver's door switchpack fault</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>■ Check the access switch operation and repair/renew as necessary. Refer to the electrical circuit diagrams and check the wiring harness between the access switch on driver's door and the air suspension control module for continuity. Repair/renew as necessary</li> </ul>