


On completing this lesson, you will be able to:

- Follow the recommended route for diagnostics.
- Use the chart to process further diagnosis by eliminating certain scenarios or components.

RANGE ROVER (LP)



System Checks

Preliminary Checks

This section covers possible air suspension component faults. However a preliminary visual check of the components within the system plus any relevant fuses and relays should be carried out prior to undertaking any detailed fault diagnosis procedures. Full diagnostics are covered by the T4 diagnostic equipment.

Hard Ride

Possible Cause	Remedy
Loss of air pressure in the system resulting in the chassis bump stops resting on the front and rear axles	Check air system components for faults and air suspension harness for leaks
Incorrect ride height	Re-calibrate the air suspension system. Refer to T4 diagnostic equipment

Permanent Standard Ride Height

Possible Cause	Remedy
Height sensor(s) inoperative due to loose or disconnected multi-plug	Reconnect multi-plug
Height sensor linkage disconnected or damaged	Reconnect or renew height sensor linkage
Faulty height sensor(s)	Renew height sensor(s)
Leaking air supply to air spring(s)	Check air harness connections and pipes for damage or scoring
Faulty or leaking air spring diaphragm	Renew air spring assembly
Faulty pressure switch	Refer to T4 diagnostic equipment

Air Suspension System Faulty or Inoperative

Possible Cause	Remedy
Blown air suspension system fuse	Check for cause and renew Fuse 44
Blown fuse covering Height Control or Inhibit Switch	Check for cause and renew Fuse 17
Faulty 'Height Control' switch resulting in the vehicle height remaining at last height setting until the engine is switched off	Refer to T4 diagnostic equipment to confirm the fault and renew 'Height Control' switch
Faulty 'Inhibit' switch leading to vehicle not operating automatically between standard and low modes	Refer to T4 diagnostic equipment to confirm the fault and renew 'Inhibit' switch
Compressor inoperative resulting in no air pressure due to loose or disconnected multi-plug	Check and reconnect compressor multi-plug
Blown compressor maxi fuse	Check for cause and renew maxi Fuse 2
Faulty compressor relay leading to the compressor running continuously	Renew relay RL20
Loss of air pressure in the air pressure system	Check the air system components for faults and air harness for leaks
Faulty delay relay If the delay relay fails with a short circuit the system will be powered constantly resulting in a flat battery	Renew relay AMR3284

Excessive Front End Body Roll


Possible Cause	Remedy
Deflated air spring	Check air system components for faults and air harness for leaks. Rectify or renew components where necessary
Faulty valve block	Refer to T4 diagnostic equipment

Vehicle Leaning and Air Suspension Inoperative

Possible Cause	Remedy
Faulty height sensor	Refer to T4 diagnostic equipment to locate faulty height sensor. Renew height sensor and re-calibrate air suspension system
Incorrect height sensor calibration	Re-calibrate the air suspension system

Message center Warnings - Requiring Driver Response

Message	Meaning	Solution
EAS MANUAL	Vehicle locked in Access	EAS warning! The vehicle is being driven on its bump stops
SLOW 20 MPH MAX	Road speed is too high for current ride height	Slow down to less than 20 mph
EAS FAULT	There is a fault with the air suspension	Consult your Land Rover dealer
SLOW 35 MPH MAX	Air suspension fault	Slow to 35 mph and seek qualified assistance

RANGE ROVER (LM)**System Checks**

The air suspension system calibration must be carried out after the following components have been replaced:

- Air suspension ECU
- Height sensors
- Body panel incorporating suspension fixing points

To calibrate the air suspension system connect the T4 diagnostic equipment and follow the on-screen instructions.

Calibration Notes:

The vehicle can be calibrated laden or un-laden, but Gross Vehicle Weight (GVW) must not be exceeded.

Tires must be all the same size and at the correct tire pressures.

Ensure the floor used as the calibration area is level and smooth in all directions to enable calibration to be carried out successfully.

Diagnostics

The air suspension ECU can store fault codes which can be retrieved using the T4 diagnostic equipment.

The diagnostic information obtained through the diagnostic socket which is located in the fascia, in the driver's stowage tray.

The fascia secured socket is protected by a hinged cover.

The diagnostic socket allows the exchange of information between the various ECU's on the various bus systems and the T4 diagnostic equipment or a diagnostic tool.

This allows fast retrieval of diagnostic information and programming of certain functions using the T4 diagnostic equipment or suitable diagnostic tool.

Fault Detection

The air suspension ECU performs fault detection and plausibility checks.

Fault detection is limited to faults that the ECU can directly measure.

These faults are as follows:

- Sensor hardware faults
- Valve hardware faults
- Sensor faults
- Actuator faults
- Bus failure
- ECU hardware errors

Plausibility Checks

Plausibility checks are checks on signal behavior.

These are as follows:

Average height does not change correctly:

- Height changes slowly
- Suspension moves in the wrong direction

Reservoir pressure:

- Does not increase when reservoir filling requested
- Does not decrease when reservoir used to lift vehicle
- Does not decrease when reservoir is vented
- Pressure varies too much when inactive

Compressor temperature:

- Increases when compressor inactive
- Does not increase when compressor active

'Energy' used to change height of corner:

- Too much energy used
- Height change takes too long
- Long term filtered height does not reach target

Sensor activity:

- Signal floating
- Inconsistent signal characteristic (signal on one axle is varying but the other side remains static)
- Constant articulation when moving

Ride Quality

When a fault is detected, the ECU will attempt to maintain a comfortable ride quality whilst maintaining a restricted functionality of the air suspension system.

System Functionality

The system functionality when a fault exists depends on the severity of the detected fault.

Faults are defined as minor or major.

Minor faults:

- Most sensor faults (hardware or plausible faults)
- Cross link valve failure
- Reservoir valve failure

For most minor faults, height changes are inhibited except for a return to the standard height setting.

If the air suspension system is not in standard height mode, the air suspension ECU will respond with a request for a manual or automatic height change to return the vehicle to the standard ride height setting.

The air suspension ECU will continue to level the vehicle at the current ride height.

Major faults:

- Compressor faults
- Plausibility errors, for example:

- Average height does not increase when lifting and vehicle is moving. This could be caused by a compressor fault or fault in the reservoir valve.
- Reservoir pressure decreases when filling requested. This could be caused by a leak in the common gallery of the valve block or connecting air harness pipework.

For major system faults, the air suspension ECU will not level the vehicle at the current ride height.

The air suspension ECU freezes all height changes until it receives a manual or automatic request for height change.

The ECU will return to standard height and freezes once standard height is achieved.

Speed Signal Loss

If the air suspension ECU loses information regarding vehicle speed, the ECU cannot determine if the current ride height is suitable for the vehicle speed.

The ECU immediately returns to a 'Default Height', which is 20 mm below stand ride height (Motor way ride height).

Once at the default height setting, the air suspension ECU will continue to level the vehicle at this height setting.

The loss of speed signal could be due to a fault in the CAN bus network or the ABS ECU.

A speed signal fault is unlikely to be a fault in the air suspension ECU.

This fault could be caused for example, by disconnecting the battery and not re-calibrating the steering sensor immediately upon battery re-connection.

In this case a CAN bus fault is recorded in the error memory.

If this fault is seen, other ECU's using the CAN bus should also be checked for fault codes.

When the fault is repaired, the air suspension ECU will resume full functionality, but the CAN error remains in memory.

ECU Hardware Fault

If the suspension is above standard ride height and the ECU cannot lower the suspension or cannot determine the vehicle height, all height changes will be frozen.

The ECU will issue a message on the CAN bus which is received by the instrument pack, which displays a maximum advisable speed in the message center of '35MPH'.

An immediate freeze of the vehicle height is caused by the following:

- Failure of more than one height sensor
- Implausible articulation detected
- Valve or solenoid failure (does not include reservoir valve)
- Stuck corner or whole vehicle diagnosed used plausibility of sensor inputs

If the air suspension ECU has a hardware fault, the ECU will disable all air suspension functions.

Detectable hardware errors include memory error, ECU failure or calibration errors.

Fault Messages

The air suspension has two methods which it can use to inform the driver of a fault in the air suspension system.

The methods used are as follows:

- Instrument pack message center
- Rotary control switch LED's

LED's

When minor faults occur and the air suspension ECU is able to level the vehicle to the 'current ride height', the rotary control switch LED's will display the current ride height.

When the vehicle returns to the standard ride height all further height changes are disabled, the 'Hold LED' in the rotary control switch will be permanently illuminated.

If the air suspension ECU suffers a major failure and there is no air suspension control, all the rotary control switch LED's will remain unlit.


Messages

If a fault occurs and the ECU can determine the ride height and the vehicle is not above the standard ride height setting, the driver will be notified by an 'AIR SUSP. INACTIVE' message in the message center.

If the air suspension ECU cannot determine the ride height of the vehicle the 'AIR SUSP. INACTIVE' message is accompanied with an alternating 'MAX 35MPH' message.

Bus Network

Bus Network Connection



Bus Network Connection


Connection Type:

- A = Hardware
- B = 'K' Bus

- C = Diagnostic bus
- D = CAN bus

Item	Description	Item	Description
1.	Fuse 15A - Permanent supply	13.	Reservoir pressure sensor
2.	Fusible link 100A	14.	Valve block
3.	Fuse 50A	15.	Front cross link valve
4.	Air suspension relay	16.	Rear cross link valve
5.	Compressor and motor	17.	LHR height sensor
6.	Temperature sensor	18.	RHR height sensor
7.	HP exhaust valve	19.	LHF height sensor
8.	Exhaust valve	20.	RHF height sensor
9.	Control switch	21.	ABS ECU
10.	Body Control Unit (BCU)	22.	Instrument cluster
11.	Air suspension ECU	23.	Diagnostic socket
12.	Driver door module (access mode switch)		

Pneumatic Circuit



Pneumatic Circuit

Item	Description	Item	Description
1.	LHF damper /air spring	12.	Compressor inlet /exhaust valve
2.	Front cross link valve	13.	HP exhaust valve
3.	RHF damper /air spring	14.	Exhaust pilot valve
4.	LHF corner valve	15.	Pressure limiting valve
5.	Reservoir valve	16.	Electric motor
6.	RHF corner valve	17.	Pressure relief valve
7.	RHR corner valve	18.	Restriction
8.	LHR corner valve	19.	Drier unit
9.	RHR air spring	20.	Compressor
10.	Rear cross link valve	21.	Reservoir
11.	LHR air spring	22.	Pressure sensor

2 . T4 Fault Code 53 (ECU Fault)

3 . T4 Fault Code 55 (ECU Calibration Fault)

4 . Communications to the EAS ECU have failed.

ECU Diagnosis

On a number of occasions it has been found that the Air Suspension ECU is being change when no fault exists with the ECU.

The ECU stores fault codes for numerous air suspension system component failures.

In the majority of cases, changing the ECU will re-activate the system and may appear to have rectified the fault, but it will not solve the root cause of the problem.

Therefore an Air Suspension ECU Diagnosis procedure has been implemented to prevent this occurrence from being repeated.

ECU Fault Reasons

There are only four reasons for changing the Air Suspension ECU:

1 . T4 Fault Code 52 (ECU Memory Fault)

Bulletin LM204-001 04 2005

Bulletin LM204-001 04 2005 details the way that these four Fault Codes should be diagnosed before replacing an ECU.


All other problems that appear to be ECU related are due to other components and/or wiring/air harness faults.

Normal fault diagnosis should be used for component and harness faults.

The solving of height sensor problems should always be accompanied by re-calibrating the vehicle trim heights.

Should a customer express concern regarding air suspension, refer to the Diagnostic Procedure detailed in the bulletin for correct system diagnosis before changing the ECU.

Discovery Series II



System Checks

Failures are indicated by the SLS warning lamp in the bottom left corner of the instrument pack illuminating continuously in an amber color.

The SLABS ECU can be interrogated via T4 diagnostic equipment to:

- Diagnose faults stored in the ECU memory, current or historic
- Test individual parts of the system

- Initialize a SLABS ECU for operation and configuration of functionality
- T4 diagnostic equipment will also be required to calibrate the settings of new height sensors and configure the remote transmitter (if applicable).

The following tables show the type of system failures and their effects on the system operation.

Height Sensors

Failure	Effect
Sensor output stuck at 5v	Vehicle will not level
Sensor output stuck at 0v	Vehicle will not level
Mechanical link between radius arm and sensor broken	Vehicle will not level

Door Switch Inputs

Failure	Effect
Harness leads for open doors are broken or shorted to VBatt	Air suspension levels when one or more doors are open
Harness leads to door(s) shorted to earth	Air suspension will not level

SLS off-road mode switch

Failure	Effect
Fault in wiring harness	Off-road mode cannot be selected
Failure of off-road mode switch	Off-road mode is activated when switch has not been selected

Air supply unit air control valves


Failure	Effect
Valves open or short circuit	Vehicle does not level or levels unevenly

Air supply unit compressor

Failure	Effect
Faulty relay, harness fault or compressor fault	Vehicle does not level upwards

Connector Details

ECU Connectors



Connector Information

Connector Pin Detail - C0504


Pin No	Description	Input or Output
C0504-1	Battery supply	Input
C0504-2	Ignition supply	Input
C0504-5	'K' line (diagnostics)	Input/Output
C0504-12	Ground	Input

Connector Pin Detail - C0654

Pin No	Description	Input or Output
C0654-1	Left height sensor supply	Output
C0654-2	Left height sensor ground	Input
C0654-3	Left height sensor feedback signal	Input
C0654-4	Right height sensor supply	Output
C0654-5	Right height sensor ground	Input
C0654-6	Right height sensor feedback signal	Input

Connector Pin Detail - C0655

Pin No	Description	Input or Output
C0655-1	Driver's door switch	Input
C0655-2	Passenger and tailgate door switches	Input
C0655-3	Left air valves	Output
C0655-4	Right air valve	Output
C0655-5	Exhaust valve	Output
C0655-6	Air compressor (SLS relay)	Output
C0655-7	Audible warning	Output
C0655-8	SLS warning lamp	Output
C0655-11	ORM switch /ORM warning lamp	Input/Output
C0655-12	Remote handset raise /lower signal	Input

DISCOVERY 3 / LR3**System Checks**

The air suspension control module can store fault codes which can be retrieved using the T4 diagnostic unit.

Diagnostic information is obtained via the diagnostic socket which is located in the lower instrument panel closing panel, on the driver's side, below the steering column.

The diagnostic socket allows the exchange of information between the various control modules on the bus systems and T4 system or diagnostic tool.

This allows the fast retrieval of diagnostic information and programming of certain functions using the T4 system.

Fault Detection

The air suspension control module performs fault detection and plausibility checks.

Fault detection is limited to faults that the control module can directly measure:

- Sensor electrical hardware faults
- Valve electrical hardware faults
- Sensor and actuator supply faults
- Bus failures
- Control module hardware errors

Plausibility checks are checks on signal behavior, as follows:

Height Changes

- Average height does not change correctly
- Height changes too slowly

Gallery Pressure

- Does not increase fast enough when reservoir filling requested
- Increases when system is inactive
- Too low when lifting is requested
- Increases too rapidly when filling reservoir
- Does not decrease when gallery is vented
- Pressure varies too much when inactive

Compressor Temperature

- Sensor voltage too large - head and brush sensors (short circuit to battery)
- Takes too long to be readable after suitable compressor run time - head and brush sensors
- Does not increase when compressor active - head sensor only

Sensor Activity

- Signal floating
- Constant articulation when moving

When a fault is detected, the air suspension control module will attempt to maintain a comfortable ride quality and where possible will retain as much functionality as possible.

The system functionality depends on the severity of the fault.

Fault Categories

Faults are categorized into order of severity and effect on the system as follows:

- 1 = Minor fault
- 5 = Major fault

Height sensor faults (hardware faults) and reservoir valve block failure

- Retain full functionality with no 'refinements'
- Cross-link valves inoperative
- No compensation for uneven surfaces

Pressure sensor faults, compressor faults, corner valves stuck shut

- Road speed signal not available
- Vehicle returns to on-road mode height when next requested
- Levels at 'current' height

Reservoir valve stuck open, exhaust valve stuck shut if below on-road mode height, corner valves stuck open if above on-road mode height

- Vehicle returns to on-road mode height when next requested
- Does not level at 'current' height

Failure of multiple height sensors, cross-articulation when driving, calibration corrupted

- Vehicle lowers to bump stops

ABS module failure, CAN bus failure

- If the air suspension control module loses communications with the ABS module or the ABS module reports a fault, the air suspension control module immediately returns to the 'default' height, which is below the on-road ride height
- Once at the default height, the control module will continue to level the vehicle at this height
- It is unlikely that the fault will be in the air suspension control module
- When the fault is repaired, the air suspension control module will resume full functionality but the error will remain in the control module memory

For major faults the control module will not level the vehicle at the 'current' ride height.

The control module freezes height changes until it receives a manual or automatic request for height change.

The control module will return to standard height if possible and freezes once standard height is achieved.

If the suspension is above the on-road height and the air suspension control module cannot lower the suspension, all height changes will be frozen.

ABS / CAN Failures

The control module will issue a message on the high speed CAN bus which is received by the instrument cluster which displays a maximum advisable speed in the message center.

An immediate 'freeze' of the vehicle height is caused by the following:

- Failure of more than one height sensor - vehicle on bump stops
- Implausible articulation symptoms detected - vehicle on bump stops
- Valve or solenoid failure - corner valve stuck open below on-road height or exhaust valve stuck shut above on-road height
- Stuck corner or whole vehicle (diagnosed using plausibility of the sensor inputs)

If height change is not possible, e.g. exhaust valve failed closed at off-road height or compressor failed at access height, the control module will not level or change height.

If the air suspension control module has a hardware fault, the control module will disable all air suspension functions.

Detectable hardware errors include memory error, control module failure and calibrations errors.

Fault Messages

The air suspension has two methods which it can use to inform the driver of a fault in the air suspension system; the air suspension switch LED's and the instrument cluster message center.

When minor faults occur and the air suspension control module is able to level the vehicle to the 'current' ride height, the air suspension switch LED's will display the current ride height.

If the air suspension control module suffers a major failure and there is no air suspension control, all the control switch LED's will remain off.

If a fault occurs and the air suspension control module can determine the ride height and the vehicle is not above on-road height, the driver will be notified via an 'air suspension fault max speed 18.6 mph (30 km/h)' warning in the message center.

If the control module cannot determine the height of the vehicle, or the vehicle is above on-road height, cannot be lowered and the vehicle speed is too high, an air suspension fault message is displayed.

If the vehicle is restricted to on-road height an air suspension fault normal height only message is displayed.

Connector Information**Connector Pin Detail - C2030**

Pin No	Description	Input or Output
1	Rear control valve - Cross link valve - positive (+)	Output
2	Not used	Not used
3	Not used	Not used
4	Not used	Not used
5	Air supply unit - Motor temperature sensor signal	Input
6	Not used	Not used
7	Air supply unit - Motor temperature sensor - Ground	Input
8	Switch pack display - Raising LED	Output
9	Switch pack display - Lowering LED	Output
10	Switch pack display - On-road mode LED	Output
11	Rear control valve - Cross link valve - negative (-)	Input
12	Not used	Not used
13	Not used	Not used
14	Not used	Not used
15	Not used	Not used
16	Not used	Not used
17	Switch pack display - Crawl mode LED	Output
18	Switch pack display - Access mode LED	Output
19	Not used	Not used
20	Input Switch pack - Raise switch signal	Input

Connector Pin Detail - C2320

Pin No	Description	Input or Output
1	Air supply unit voltage signal input from Air supply unit relay	Input
2	Reservoir control valve - Pressure sensor - 5 volt supply	Output
3	Reservoir control valve - Pressure sensor - Signal	Input

Pin No	Description	Input or Output
4	Reservoir control valve - Pressure sensor - Ground	Input
5	Air supply unit - Exhaust valve - Negative (-)	Input
6	Air supply unit - Exhaust valve - Positive (+)	Output
7	Not used	Not used
8	Not used	Not used

Connector Pin Detail - C2321


Pin No	Description	Input or Output
1	12V Permanent battery supply	Input
2	Compressor temperature sensor - Signal	Input
3	Front LH height sensor - 5 Volt supply	
4	Front LH height sensor - Signal	Input
5	Front LH height sensor - Ground	Input
6	Air supply unit relay coil - positive	
7	Air supply unit relay coil - ground	Input
8	Reservoir control valve coil - positive (+)	
9	Front control valve - RH corner valve - negative (-)	Input
10	Front control valve - RH corner valve - positive (+)	
11	Front control valve - LH corner valve - negative (-)	Input
12	Front control valve - LH corner valve - positive (+)	
13	Not used	Not used
14	Front RH height sensor - 5V supply	
15	Front RH height sensor - signal	Input
16	Front RH height sensor - ground	Input
17	Compressor temperature sensor - ground	Input
18	Not used	Not used
19	Not used	Not used
20	Not used	Not used

Pin No	Description	Input or Output
21	Reservoir control valve coil - negative (-)	Input
22	Front control valve - cross link valve - positive (+)	
23	Front control valve - cross link valve - negative (-)	Input
24	Ground	Input


Connector Pin Detail - C0867

Pin No	Description	Input or Output
1	Rear control valve - LH corner valve positive (+)	Output
2	Rear control valve - LH corner valve negative (-)	Input
3	Door status signal from CJB	Input
4	Switch pack - Lower switch signal	Input
5	Rear LH height sensor - 5v supply	Output
6	Rear LH height sensor - Signal	Input
7	Rear LH height sensor - Ground	Input
8	Rear RH height sensor - 5v supply	Output
9	Rear RH height sensor - Signal	Input
10	Rear RH height sensor - Ground	Input
11	Rear control valve - RH corner valve positive (+)	Output
12	Rear control valve - RH corner valve negative (-)	Input
13	Air suspension control - CJB signal	Input
14	Switch pack display - LED ground	Input
15	Switch pack display - LED high	Output
16	CAN IN positive (+)	Input
17	CAN OUT positive (+)	Output
18	CAN OUT negative (-)	Input
19	CAN IN negative (-)	Output
20	12v ignition switch supply	Input

Control Schematic



Item	Description	Item	Description
1.	Fuse 26E (20 amp)	12.	Exhaust valve solenoid
2.	Fusible link 11E (30 amp)	13.	Air suspension control module
3.	Ignition switch	14.	Central junction box (CJB)
4.	Fuse 35P (5 amp)	15.	Reservoir control valve
5.	Fusible link 10E (60 amp)	16.	Air suspension control switch
6.	Air supply unit relay	17.	Front valve block
7.	Fuse 3E (5 amp)	18.	Rear valve block
8.	Air supply unit	19.	RHR height sensor
9.	Compressor temperature sensor	20.	LHR height sensor
10.	Motor	21.	RHF height sensor
11.	Motor temperature sensor	22.	LHF height sensor

2006MY Range Rover (LM)**System Checks**

The air suspension control module can store fault codes which can be retrieved using T4.

The diagnostics information is obtained via the diagnostic socket which is located in the instrument panel, in the drivers stowage tray.

The socket is secured in the instrument panel and protected by a hinged cover.

The diagnostic socket allows the exchange of information between the various control modules on the bus systems and T4 or a diagnostic tool.

This allows the fast retrieval of diagnostic information and programming of certain functions using T4.

The air suspension control module performs fault detection and plausibility checks.

Fault detection is limited to faults that the control module can directly measure, as follows:

- Sensor electrical hardware faults
- Valve electrical hardware faults
- Sensor and actuator supply faults
- Bus failures
- Control module hardware errors.

Plausibility checks are checks on signal behaviour, as follows:

- Average height does not change correctly
- Height changes too slowly
- **Gallery Pressure**
 - Does not increase fast enough when reservoir filling requested
 - Increases when system is inactive
 - Too low when lifting is requested

- Increases too rapidly when filling reservoir
- Does not decrease when gallery is vented
- Pressure varies too much when inactive.
- **Compressor Temperature**
 - Sensor voltage too large - head and brush temperature sensor (short circuit to battery)
 - Takes too long to be readable after suitable compressor run time - head and brush temperature sensor
 - Does not increase when compressor is active - head temperature sensor only.
- **Sensor Activity**
 - Signal floating
 - Constant articulation when moving.

When a fault is detected, the control module will attempt to maintain a comfortable ride quality and where possible will retain as much functionality as possible.

The system functionality depends on the severity of the fault.

Faults

Faults are categorised into order of severity and effect on the system as follows:

- Height sensor faults (hardware faults) and reservoir valve block failure
 - Retain full functionality with no 'refinements', e.g. cross-link valves inoperative, no compensation for uneven surfaces.
- Pressure sensor faults, compressor faults, corner valves stuck shut
 - Road speed signal not available
 - Vehicle returns to on-road height when next requested
 - Levels at 'current' height.
- Reservoir valve stuck open, exhaust valve stuck shut if below on-road height, corner valves stuck open if above on-road height

- Vehicle returns to on-road height when next requested
- Does not level at 'current' height.
- Failure of multiple height sensors, cross-articulation when driving, calibration corrupted
 - Vehicle lowers to bump stops.
- ABS module failure, CAN bus failure
 - If the air suspension control module loses communications with the ABS module or the ABS module reports a fault, the air suspension control module immediately returns to the default height, which is below the on-road height. Once at the default height, the control module will continue to level the vehicle at this height. It is unlikely that the fault will be in the air suspension control module. When the fault is repaired, the air suspension control module will resume full functionality but the error will remain in the control module memory.

For major faults the control module will not level the vehicle at the 'current' ride height.

The control module freezes height changes until it receives a manual or automatic request for height change.

The control module will return to on-road height and freezes once on-road height is achieved.

If the suspension is above the on-road height and the air suspension control module cannot lower the suspension, all height changes will be frozen.

The control module will issue a message on the high speed CAN bus which is received by the instrument cluster which displays a maximum advisable speed in the message center.

An immediate 'freeze' of the vehicle height is caused by one of the following:

- Failure of more than one height sensor - vehicle on bump stops
- Implausible articulation symptoms detected - vehicle on bump stops
- Valve or solenoid failure - corner valve stuck open below on-road height or exhaust valve stuck shut above on-road height
- Stuck corner or whole vehicle (diagnosed using plausibility of the sensor inputs).

If height change is not possible, e.g. exhaust valve failed closed at off-road height or compressor failed at access height, the control module will not level or change height.

If the air suspension control module has a hardware fault, the control module will disable all air suspension functions. Detectable hardware errors include memory error, control module failure, calibrations errors.

Fault Messages

The air suspension has two methods which it can use to inform the driver of a fault in the air suspension system; the air suspension control switch LEDs and the instrument cluster message center.

If the air suspension control module suffers a major failure and there is no air suspension control, all the control switch LEDs will remain unlit.

If a fault occurs and the control module can determine the ride height and the vehicle is not above on-road height, the driver will be notified via a message in the message center.

If the control module cannot determine the height of the vehicle, or the vehicle is above on-road height and cannot be lowered, a message is displayed and accompanied with a maximum speed message.

The following table shows messages related to the air suspension system.

Message	Other Warnings	Meaning
SUSPENSION FAULT NORMAL HEIGHT ONLY	One chime	A fault has been detected in the air suspension system and only on-road (normal) height is available.
SUSPENSION FAULT MAX SPEED 30MPH (50KPH)	Two chimes repeated every 30 seconds if speed exceeded	A major fault has been detected in the air suspension system and it is unable to control the height correctly.
SLOW DOWN OR VEHICLE WILL RAISE	Two chimes	Vehicle will automatically raise to on-road height if speed increases.
SLOW DOWN OR VEHICLE WILL LOWER	One chime	Vehicle will automatically lower to on-road height from off-road height if speed increases.
SUSPENSION WILL LIFT WHEN SYSTEM COOLED	None	Air suspension compressor is cooling. Lifting will resume when compressor has cooled.

Message	Other Warnings	Meaning
VEHICLE LIFTING SLOWLY	None	Vehicle is lifting slowly from compressor only because reservoir is empty. Only displayed if lift time exceeds 12 seconds.
EXTENDED MODE	One chime	Vehicle body has become grounded on an obstacle.
RESET HEIGHT IF CLEAR OF OBSTACLE	None	Press air suspension rotary control switch downwards to exit the extended mode.
SUSPENSION LOCKED AT ACCESS HEIGHT	None	Crawl mode has been selected.
CLOSE DOORS TO CHANGE HEIGHT	One chime	Re-select height if door was open for more than 90 seconds or air suspension height change is restricted because a door is open.
SPEED TOO HIGH TO CHANGE HEIGHT	One chime	A height change has been requested that is not allowed, e.g. vehicle speed too high to select off-road height.
SUSPENSION FAULT	One chime	A fault has been detected in the air suspension system.
START ENGINE TO RAISE VEHICLE	None	The vehicle height can only be raised if the engine is running.
SUSPENSION LOWERED	None	The vehicle has lowered to access height because of a failure of another vehicle system.

The control module then uses a software model to operate the compressor as required.

Reservoir


The reservoir supplies pressurised air to the four air springs, via the reservoir valve block, to enable the air suspension system to raise the vehicle more quickly.

The air suspension control module assumes the reservoir has sufficient pressure, which is measured before a vehicle raise is started.

System Pneumatic Circuit

The following schematic diagram shows the connection relationship between the air supply unit, the reservoir, the reservoir valve block, the cross-link valves and the air springs.

System Schematic Circuit Diagram




E59737

Schematic Call Out Table

Item	Description
1.	Front left hand air spring
2.	Front axle valve block
3.	Cross link valve
4.	Front right hand air spring
5.	Front left hand corner valve
6.	Front right hand corner valve
7.	Reservoir valve
8.	Reservoir valve block
9.	Pressure sensor
10.	Rear right hand corner valve
11.	Rear left hand corner valve
12.	Rear right hand air spring
13.	Cross link valve
14.	Rear axle valve block
15.	Rear left hand air spring
16.	Pilot exhaust valve
17.	Pressure relief valve and exhaust valve
18.	Motor temperature sensor
19.	Electric motor
20.	Compressor
21.	Air drier assembly
22.	Compressor temperature
23.	Reservoir

Air Suspension Control Diagram

NOTE: A = Hardwired; D = CAN Bus high speed



Item	Description
1.	Ignition switch
2.	Fuse 7P (5 amp) - CJB Ignition switch position II supply
3.	Fuse 57P (20 amp) - Permanant supply from battery
4.	Maxi fuse 62 (40 amp) - CJB
5.	Battery
6.	Fusible link 5P (100 amp) - Permanant supply from battery
7.	Maxi fuse 22R (60 amp) - Permanant supply from battery
8.	Air suspension relay in rear fuse box
9.	Fuse 13R (5 amp) - Battery voltage signal to control module
10.	Compressor and motor
11.	Pilot exhaust valve solenoid
12.	Compressor temperature sensor
13.	Reservoir valve block
14.	Exhaust valve
15.	Control switch
16.	Generic Electronic Module (GEM)
17.	Driver's door module access mode switch
18.	Rear valve block
19.	Front valve block
20.	Left hand rear height sensor
21.	Right hand rear height sensor
22.	Air suspension control module
23.	Left hand front height sensor
24.	Right hand front height sensor
25.	CAN bus interface with other control modules
26.	Diagnostic socket