

Application: Harmon Kardon/Becker Traffic Pro.(Freelander Model)
Instructions for installing an external audio source (MP3/iPod)

- Remove the C3 (part of the BLUE connector) Socket connector from your radio. If your radio does not have one, find the one enclosed in the cable kit.
- Locate the set of female RCA jacks from the modification kit.

OR just use a standard 3.5mm Audio lead.

- Insert the **brown lead into pin #18 of the C3 Socket. – Signal Ground**
- Insert the **yellow lead into pin #19 of the C3 Socket. – Left Channel**
- Insert the **red lead into pin #20 of the C3 Socket. – Right Channel**



**** When selecting this option, you will not be able to use an external CD Changer at the same time since they both use the same audio input lines. ****

To select Auxiliary Input for Harmon/Kardon Traffic Pro:



Turn radio ON. Press and hold the  button for 8 seconds, until **Sub Menu** is displayed.

Press the button located directly under **AUX** on the display to change the present setting from OFF to **ON**.

Turn radio OFF. Auxiliary Audio Input has now been activated.

When properly connected and the radios “Auxiliary Input “ is selected as per instructions above, you will be able to play external audio sources through the radio system.

More useful info is available from - <http://z3ers.com/01/081501/becker.html>