



All welds to be strong as feck and do not weld on the inside or outside...if you do, grind it back to permit correct fitment!

# 200TDi Crank Pulley Restraining Tool

Scale 1:2 @ A3

Drawn (badly) by Saint.V8 07/05/2015