



M417063A

Item	Part Number	Description
1	-	Rear output shaft
2	-	Rear output housing
3	-	Bolt - rear output housing
4	-	Speedometer drive gear
5	-	Spacer
6	-	Output shaft bearing
7	-	Circlip
8	-	Oil seal
9	-	Mud shield
10	-	Output shaft flange
11	-	Felt washer
12	-	Steel washer
13	-	Self-locking nut
14	-	Transmission brake backplate
15	-	Bolt - transmission brake backplate
16	-	Transmission brake drum
17	-	Countersunk screw
18	-	Speedometer driven gear
19	-	O-ring
20	-	Speedometer driven gear housing
21	-	Seal
22	-	O-ring
23	-	Vehicle speed sensor (if fitted)
24	-	Allen screw (if fitted)

The rear output housing carries the output shaft and flange and the speedometer drive and driven gears. A mechanically operated transmission brake is attached to the housing, the brake drum being attached to the output flange.

The rear output shaft is supported in the rear output housing by a single bearing and is splined into the differential rear shaft. The output shaft also carries the speedometer drive gear, which meshes with the speedometer driven gear located in the rear output housing.

A differential lock warning lamp switch operated by movement of the selector fork and shaft is screwed into the top of the output housing.