

Controls overview

CONTROLS

1. Map reading lamp switch.
2. Main interior lamp switch.
3. Sunroof open/close switch.
4. Airbag status indicator.
5. Adaptive cruise control gap setting.
6. High beam/Direction indicator/Trip computer switch.
7. Downshift gear paddle.
8. Audio system control.
9. Instrument panel and message centre.
10. Vehicle information control.
11. Upshift gear paddle.
12. Wiper/washer controls.
13. START/STOP button.
14. Master locking switch.
15. Hazard warning lamp switch.
16. Display/touch screen.
17. Audio system and controls.
18. Glove box switches.
19. Heater/air conditioning control.
20. Tailgate opener.
21. Parking aid switch.
22. High/Low range switch.
23. Electric parking brake.
24. Hill descent control (HDC) switch.
25. Air suspension switch.
26. Terrain response control.
27. Main gearbox selector
28. Rear climate control master switch.
29. Dynamic stability control switch.
30. Telephone controls.
31. Voice recognition switch.
32. Heated steering wheel switch.
33. Horn switches.
34. Cruise control switches.
35. Electric steering column adjuster.
36. Bonnet release.
37. Terrain response switch.
38. Drive selector.
39. Instruments, clock and switches illumination dimmer control.
40. Rear fog lamp switch.
41. Front fog lamp switch.
42. Lamps master switch.
43. Electric mirror controls.
44. Mirror selector switch.
45. Electric window controls.
46. Electric window rear isolator switch.
47. Power folding mirrors.
48. Air suspension access height switch.

