


Electronic Engine Controls - ID4 2.2L Diesel - Accelerator Pedal Position (APP) Sensor

Removal and Installation

Removal


NOTE: Removal steps in this procedure may contain installation details.

1. Torque: 25Nm



E139652

- 2.



E89797

Installation

1. To install, reverse the removal procedure.