

3. Connect rod to locking barrel lever and retain with spring clip.
4. Install door reinforcement panel.  
For additional information, refer to: Front Door Reinforcement Panel (501-03, Removal and Installation).