


[Connect](#) (414-01 Battery, Mounting and Cables, General Procedures).

3.  **WARNING:** The spilling of fuel is unavoidable during this operation. Make sure that all necessary precautions are taken to prevent fire and explosion.


Drain the fuel tank.

For additional information, refer to: [Fuel Tank Draining](#) (310-00 Fuel System - General Information, General Procedures).

4.  **CAUTION:** Make sure that all openings are sealed. Use new blanking caps.


Disconnect the fuel tank filler pipe.

- Loosen the clip.




5. Release the fuel tank vent line.

- Release from the clip.
- Cut the cable tie.



6. Using the special tool, support the fuel tank.



7. Lower the fuel tank.