

Wire colours

B	Black	P	Purple
G	Green	R	Red
K	Pink	S	Slate
Lg	Light green	U	Blue
N	Brown	W	White
O	Orange	Y	Yellow

Key to items

1	Battery	19	Fuel pump relay	28	Ambient air temp. sensor
4	Ignition switch	20	Fuel pump/gauge sender unit	29	Throttle position switch
5	Under seat fusebox	21	Fuse holder	30	Crank position sensor
6	Passenger fusebox	22	EGR valve	31	Fuel rail temp. switch
10	Glow plugs	23	MAF sensor	32	Coolant temp. sensor
15	Engine management control unit	24	Fuel injectors	33	EGR inlet valve
16	Glow plug relay	25	Transmission switch (hi/lo)	34	Satellite fusebox
17	Inertia switch	26	Inlet air temp. sensor	35	Engine cooling fan relay
18	Main relay	27	MAP sensor	36	Engine cooling fan

Diagram 3

Engine management
- TD5 models