



WARNING: Tyre pressures must be checked with the tyres cold, as the pressure is about 0.21 bar (3 lbf/in²) 0.2 kg/cm² higher at running temperature. If the vehicle has been parked in the sun or high ambient temperatures, **DO NOT** reduce the tyre pressures, move the vehicle into the shade and wait for the tyres to cool before checking the pressures.

TYRE PRESSURES

Maximum tyre life and performance will only be obtained if the tyres are maintained at the correct pressures.

	Tyres - size and type	Normal		Emergency soft			
		All load conditions		Unladen		Laden	
		Front	Rear	Front	Rear	Front	Rear
90 M O D E L S	205R16 RADIAL-PLY bar lbf/in ² kgf/cm ²	1.9	2.4	1.1	1.1	1.1	1.6
		28	35	16	16	16	23
		2.0	2.5	1.1	1.1	1.1	1.6
	7.50R16 RADIAL-PLY bar lbf/in ² kgf/cm ²	1.9	2.7.5	1.1	1.1	1.1	1.6
		28	40	16	16	16	23
		2.0	2.8	1.1	1.1	1.1	1.6
110 M O D E L S	750R16 RADIAL-PLY bar lbf/in ² kgf/cm ²	1.9	3.3	1.1	1.1	1.1	1.8
		28	48	16	16	16	26
		2.0	3.4	1.1	1.1	1.1	1.8

General Notes:

- Emergency soft pressures should only be used in extreme conditions where extra floatation is required. Max. speed 40 km/h (25 mph). Return pressure to normal immediately firm ground is regained.
- For extra ride comfort at part load the normal rear tyre pressures may be reduced to following:
 90 models - Not more than 1050kg rear axle load.
 1.9 bar (28 lbf/in²) 2.0 kgf/cm²
 110 models - Not more than 1250 kg rear axle load.
 Cross-ply and radial tyres: 2.2 bar (32 lbf/in²) 2.25 kgf/cm²
- Towing: when vehicle is used for towing the reduced rear tyre pressures for extra ride comfort are not applicable.
 Where special tyres or tyres other than those quoted are fitted to the vehicle, consult your Land Rover Distributor or Dealer or the tyre Manufacturer for correct tyre pressures.